

# 携帯電話機液晶保護パッド

平成25年4月16日現在

Kashimura

メーカー	機種	テレパッチ対応品番			プライベートシート対応品番			メーカー	機種	テレパッチ対応品番			プライベートシート対応品番		
		専用	汎用	汎用 角度45度	汎用 角度360度	専用	汎用			汎用 角度45度	汎用 角度360度	専用	汎用	汎用 角度45度	汎用 角度360度
docomo	NEC	Disney Mobile on docomo N-03E	BP-288/758	BP-725/753/756	BP-734/735/738/739	BP-729/748	au	東芝	REGZA Phone IS11T	BP-725/753/756	△	△	△		
		MEDIAS U N-02E	BP-725/753/756	△	△	△			Windows Phone IS12T	BP-725/753/756	△	△	△		
		N-01E	BP-727/732/743/751	BP-734/735/738/739	BP-729/748	△			TOO8	BP-727/732/743/751	BP-734/735/738/739	BP-729/748	△		
		MEDIAS X N-07D	BP-288/758	△	△	△			TOO7	BP-274/731/742/750	BP-714/715/720/724	BP-716/747	△		
		MEDIAS ES N-05D	BP-725/753/757	△	△	△			REGZA Phone IS04	BP-369	BP-725/753/756	△	△		
		MEDIAS LTE N-04D	BP-725/753/757	△	△	△			TOO6	BP-274/731/742/750	BP-714/715/720/724	BP-716/747	△		
		N-03D	BP-728/733/744/752/755	BP-736/737/740/741	BP-730/749	△			lida X-RAY	BP-274/731/742/750	BP-714/715/720/724	BP-716/747	△		
		N-02D	BP-728/733/744/752/755	BP-736/737/740/741	BP-730/749	△			TOO5	BP-274/731/742/750	BP-714/715/720/724	BP-716/747	△		
		MEDIAS PP N-04D	BP-725/753/756	△	△	△			SA002	BP-274/731/742/750	BP-714/715/720/724	BP-716/747	△		
		MEDIAS WP N-06C	BP-725/753/756	△	△	△			GzOne TYPE-L-CAL21	BP-725/753/756	△	△			
docomo	パナソニック	N-05C	BP-728/733/744/752	BP-736/737/740/741	BP-730/749	△	CA007	BP-727/732/743/751	BP-734/735/738/739	BP-729/748	△				
		MEDIAS N-04C	BP-725/753/756	△	△	△	GzOne (IS11CA)	BP-375	BP-725/753	△	△				
		N-03C	BP-727/732/743/751	BP-734/735/738/739	BP-729/748	△	GzOne (IS10CA)	BP-375	BP-725/753	△	△				
		N-02C	BP-728/733/744/752	BP-736/737/740/741	BP-730/749	△	GzOne TYPE-X	BP-728/733/744/752	BP-734/735/738/739	BP-729/748	△				
		P-01E	BP-728/733/744/752	BP-736/737/740/741	BP-730/749	△	CA006	BP-727/732/743/751	BP-734/735/738/739	BP-729/748	△				
		ERUGA V P-06D	BP-725/753/757	△	△	△	CA005	BP-727/732/743/751	BP-734/735/738/739	BP-729/748	△				
		Disney Mobile P-05D	BP-725/753/757	△	△	△	ソニー	Xperia VL SOL21	BP-725/753/757	△	△				
		P-04D	BP-725/753/757	△	△	△	Xperia acro HD IS12S	BP-725/753/757	△	△					
		P-03D	BP-728/733/744/752/755	△	△	△	URBANO AFFARE	BP-728/733/744/752/755	BP-736/737/740/741	BP-730/749	△				
		P-02D	BP-725/753/756	△	△	△	Xperia acro (IS11S)	BP-374	BP-725/753/757	△	△				
P-01D	BP-728/733/744/752	△	△	△	lida G11	BP-727/732/743/751	BP-734/735/738/739	BP-729/748	△						
P-07C	BP-728/733/744/752	△	△	△	SO07	BP-728/733/744/752	BP-736/737/740/741	BP-730/749	△						
P-06C	BP-274/731/742/750	BP-714/715/720/724	BP-716/747	△	SO06	BP-728/733/744/752	BP-736/737/740/741	BP-730/749	△						
P-05C	BP-728/733/744/752	△	△	△	URBANO MOND	BP-727/732/743/751	BP-734/735/738/739	BP-729/748	△						
P-04C	BP-274/731/742/750	BP-714/715/720/724	BP-716/747	△	SO05	BP-727/732/743/751	BP-734/735/738/739	BP-729/748	△						
docomo	シャープ	スマートフォン for ジュニア SH-05E	BP-725/753/756	BP-714/715/720/724	BP-716/747	△	日立	beskey	BP-727/732/743/751	BP-734/735/738/739	BP-729/748	△			
		SH-05E	BP-274/731/742/750	BP-714/715/720/724	BP-716/747	△	京セラ	DIGNO S KYL21	BP-288/758	△	△				
		AQUOS PHONE ZETA SH-02E	BP-288/758	△	△	△	防水ケータイK012	BP-274/731/742/750	BP-714/715/720/724	BP-716/747	△				
		AQUOS PHONE SH-01E	BP-725/753/756	△	△	△	K011	BP-728/733/744/752	△	△					
		AQUOS PHONE sv SH-10D	BP-288/758	△	△	△	URBANO PROGRESSO	BP-725/753/756	△	△					
		AQUOS PHONE ZETA SH-09D	BP-288/758	△	△	△	DIGNO ISW11K	BP-725/753/756	△	△					
		AQUOS PHONE at SH-07D	BP-728/733/744/752/755	BP-736/737/740/741	BP-730/749	△	K010	BP-274/731/742/750	BP-714/715/720/724	BP-716/747	△				
		AQUOS PHONE SH-06D	BP-288/758	△	△	△	K009	BP-727/732/743/751	BP-734/735/738/739	BP-729/748	△				
		SH-05D	BP-727/732/743/751/755	BP-734/735/738/739	BP-729/748	△	K008	BP-274/731/742/750	BP-714/715/720/724	BP-716/747	△				
		Q-potPhone SH-04D	BP-725/753/755	△	△	△	K007	BP-274/731/742/750	BP-714/715/720/724	BP-716/747	△				
SH-03D	BP-728/733/744/752/755	BP-736/737/740/741	BP-730/749	△	シャープ	AQUOS PHONE SERIE SHL21	BP-288/758	△	△						
AQUOS PHONE slider SH-02D	BP-725/753/755	△	△	△	AQUOS PHONE CL IS17SH	BP-288/758	△	△							
AQUOS PHONE SH-01D	BP-288/758	△	△	△	AQUOS PHONE SL IS15SH	BP-725/753/755	△	△							
AQUOS PHONE f SH-13C	BP-725/753/757	△	△	△	AQUOS PHONE SERIE ISW16SH	BP-288/758	△	△							
SH-12C	BP-725/753/757	△	△	△	AQUOS PHONE IS14SH	BP-725/753/755	△	△							
SH-11C	BP-727/732/743/751	BP-734/735/738/739	BP-729/748	△	AQUOS PHONE IS13SH	BP-288/758	△	△							
docomo	富士通	ARROWS V F-04E	BP-288/758	△	△	△	INFOBAR 001	BP-727/732/743/751/755	BP-734/735/738/739	BP-729/748	△				
		ARROWS Kiss F-03E	BP-725/753/756	△	△	△	lida INFOBAR A01	BP-725/753/755	△	△					
		F-01E	BP-728/733/744/752	BP-736/737/740/741	BP-730/749	△	AQUOS PHONE IS12SH	BP-725/753/757	△	△					
		らくらくスマートフォン F-12D	BP-725/753/756	△	△	△	パナソニック	W62P	BP-274/731/742/750	BP-714/715/720/724	BP-716/747	△			
		ARROWS Me F-11D	BP-725/753/755	△	△	△	HTC	INFOBAR A02	BP-288/758	△	△				
		ARROWS X F-10D	BP-288/758	△	△	△	HTC EVO 3D ISW12HT	BP-725/753/757	△	△					
		F-09D ANTEPRIMA	BP-725/753/755	△	△	△	バンテック	VEGA PTL21	BP-725/753/757	△	△				
		Disney Mobile on docomo F-08D	BP-725/753/757	△	△	△	モトローラ	MOTOROLA RAZR IS12M	BP-725/753/757	△	△				
		ARROWS μ F-07D	BP-725/753/756	△	△	△	富士通	ARROWS ef FJL21	BP-725/753/757	△	△				
		F-06D	BP-728/733/744/752/755	BP-736/737/740/741	BP-730/749	△	NEC	ARROWS Z ISW13F	BP-725/753/758	△	△				
ARROWS X LTE F-05D	BP-725/753/757	△	△	△	サムスン	MEDIAS BR IS11N	BP-725/753/755	△	△						
F-04D	BP-728/733/744/752/755	BP-736/737/740/741	BP-730/749	△	サムスン	GALAXY S II ISW11SC	BP-288/758	△	△						
ARROWS Kiss F-03D	BP-725/753/755	△	△	△	SoftBank	LG	Optimus G LGL21	BP-288/758	△	△					
F-02D	BP-728/733/744/752	BP-736/737/740/741	BP-730/749	△	アップル	iPhone 4S	KD-125/126/127	BP-288/725/753	△	KD-01					
F-12C	BP-725/753/755	△	△	△	iPhone 4	BP-288/725/753	△	△	△	KD-101					
F-11C	BP-728/733/744/752	BP-736/737/740/741	BP-730/749	△	iPhone 3GS	KD-100	BP-288/725/753	△	△	KD-101					
F-10C	BP-725/753/755	△	△	△	iPhone 3G	KD-100	BP-288/725/753	△	△	KD-101					
docomo	ソニー	Xperia AX SO-01E	BP-725/753/757	△	△	△	シャープ	AQUOS PHONE XX 203SH	BP-288/758	△	△				
		Xperia SX SO-05D	BP-728/733/744/752/755	BP-736/737/740/741	BP-730/749	△	PANTONE WATERPROOF 202SH	BP-274/731/742/750	BP-714/715/720/724	BP-716/747	△				
		Xperia QX SO-04D	BP-288/758	△	△	△	PANTONE 6 200SH	BP-288/758	△	△					
		Xperia acro HD SO-03D	BP-725/753/757	△	△	△	THE PREMIUM 9 WATERPROOF 109SH	BP-728/733/744/752	BP-736/737/740/741	BP-730/749	△				
		REGZA Phone T-02D	BP-725/753/757	△	△	△	かんたん携帯 108SH	BP-274/731/742/750	BP-714/715/720/724	BP-716/747	△				
		REGZA Phone T-01D	BP-725/753/757	△	△	△	PANTONE 5 107SH	BP-725/753/755	△	△					
		CA-01C	BP-728/733/744/752	BP-736/737/740/741	BP-730/749	△	AQUOS PHONE 102SH II	BP-288/758	△	△					
		LG	Optimus LIFE L-02E	BP-288/758	△	△	AQUOS PHONE Xx 106SH	BP-288/758	△	△					
		Optimus G L-01E	BP-288/758	△	△	△	AQUOS PHONE 104SH	BP-288/758	△	△					
		Optimus it L-05D	BP-725/753/756	△	△	△	AQUOS PHONE 103SH	BP-725/753/756	△	△					
PRADA phone by LG L-02D	BP-725/753/757	△	△	△	AQUOS PHONE 102SH	BP-288/758	△	△							
Optimus LTE L-01D	BP-288/758	△	△	△	AQUOS PHONE THE HYBRID 101SH	BP-728/733/744/752	BP-736/737/740/741	BP-730/749	△						
Optimus bright L-07C	BP-725/753/756	△	△	△	京セラ	X02T	BP-288/725/753/756	△	△						
Optimus chat L-04C	BP-725/753	△	△	△	パナソニック	COLOR LIFE 3 103P	BP-274/731/742/750	BP-714/715/720/724	BP-716/747	△					
HTC	HT-03A	△	△	△	LUMIX Phone 101P	BP-725/753/756	△	△							
RIM	BlackBerry Bold 9900	BP-728/733/744/752/755	BP-736/737/740/741	BP-730/749	003P	BP-725/753/757	△	△							
BlackBerry Bold 9780	BP-727/732/743/751	△	△	△	002P	BP-274/731/742/750	BP-714/715/720/724	BP-716/747	△						
ノキア	NM850IG	BP-244	BP-45/201/275	△	NEC	MEDIAS CH 101N	BP-725/753/756	△	△						
サムヨー	SA800i	BP-234	BP-45/201/275	△	001N	BP-728/733/744/752	BP-736/737/740/741	BP-730/749	△						
サムスン	GALAXY S II LTE SC-00D	BP-379	BP-288/758	△	カシオ	930CA	BP-274/731/742/750	BP-714/715/720/724	BP-716/747	△					
GALAXY S II SC-02C	BP-373	BP-288	△	△	サムスン	001SC (AQUA STYLE)	BP-274/731/742/750	BP-714/715/720/724	BP-716/747	△					
GALAXY S	BP-362/363	BP-725/753	△	△	HTC	001HT (Desire HD)	BP-725/753/757	△	△						
HUAWEI	Ascend HW-01E	BP-288/758	△	△	X06HT	BP-288/725/753/755	△	△							
docomo	WILLCOM	WX321J	BP-45/201/275	BP-53/706/709/717/721	BP-711	7TE	STAR 7 009Z	BP-725/753/755	△	△					
		WX310J	BP-220	BP-45/201/275	BP-53/706/709/717/721	BP-711	DELL	DELL Streak Pro 101DL	BP-725/753/757	△	△				
		WX300K	BP-217	BP-45/201/275	BP-53/706/709/717/721	BP-711	HUAWEI	STREAM 201HW	BP-725/753/757	△	△				
		WX300K	BP-217	BP-45/201/275	BP-53/706/709/717/721	BP-711	京セラ	HONEY BEE 201K	BP-725/753/756	△	△				
		WX310K	BP-218	BP-45/201/275	BP-53/706/709/717/721	BP-711	富士通	ARROWS A 201F	BP-288/758	△	△				
		WX310SA	BP-219	BP-45/201/275	BP-53/706/709/717/721	BP-711	モトローラ	MOTOROLA RAZR M 201M	BP-725/753/757	△	△				
		W-ZERO3(WX003SH)	BP-227	BP-288	△	△	EM-ONE α	BP-288	△	△					
		W-ZERO3es(WX007SH)	BP-264	BP-288	△	△	EM-ONE(S01SH)	BP-288	△	△					
		EMOBILE													

・★印は汎用テレパッチ、プライベートシートの合うサイズがありませんので、適合しません。  
 ・△印はプライベートシートの合うサイズがない為、適合しません。  
 ・◇印はプライベートシートの厚みの為、角度3